



How to Install Tuf-Tite Septic Tank Risers

Things You'll Need

- Sealant rope (1 roll does 3 risers)
- Robertson Screws
- Hexagon Head Screws
- Risers (3", 6", 12" Heights)
- Riser cover
- Drill
- 1½" Tapcon Concrete Anchors

Instructions

1. Expose septic tank lid. Dig down to tank and clear dirt away from the lid.
2. Remove the lid and set it aside. Clear all dirt and debris away from surface of septic tank. Ensure that the septic tank is cleaned thoroughly around the opening.
3. Measure the width of the opening on the septic tank.
4. Fit the riser to the dimensions of the opening.
5. Measure the distance from the top of the septic tank to the top of the surface of the ground.
6. Apply the sealant rope to the bottom of the adaptor ring.
7. Press the adaptor ring onto the septic tank with the sealant rope on the bottom.
8. While applying pressure, drill ¼" holes in adaptor ring and screw in the Tapcon anchors
9. Apply the sealant rope to the crevice on the bottom of the riser.
10. Place the riser on top of the adaptor ring and secure with Robertson (□) Screws.
11. Continue steps 9 and 10 until you come up to grade.
12. Place the lid on the riser and secure with Hexagon head Screws.
13. Fill in dirt around the septic tank and riser up to and flush with the top of the riser.

Tips & Warnings

Add an optional safety screen or combination lock if there is a concern for security or safety
Ensure that the riser is completely sealed to the tank.

Newmarket Pre-Cast Concrete Products Ltd.

20 Victoria Street North

PO Box 1179, Uxbridge, Ontario L9P 1N4

Phone: 905.852.6111, **Fax:** 905.852.4340

Toll Free: 1.800.263.1297

Website: www.newmarketprecast.com **Email:** info@newmarketprecast.com